



SD card

GND
3,3 V
5 V
CS
MOSI
SCK
MISO
GND



SD card

GND
3,3 V
5 V
CS
MOSI
SCK
MISO
GND


3,3 V


4
11
13
12
GND

Arduino UNO

SD card

- GND
- 3,3 V
- 5 V
- CS
- MOSI
- SCK
- MISO
- GND





3,3 V GND

5 V GND

